Navilock Charger Plate for MAXI Charger C1037

Description

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



N° produit 65722

EAN: 4043619657223

Pays d´origine: China

Emballage: Blister

Spécifications techniques

- Suitable for
  Casio: NP30
  FUJI: NP60, NP120, BT3, S301, 1037, 1137,
  DL-S5, DL-S6, DV-4, OD525
  Kodak: K5000, K5001
  Nikon: ENEL5, EL5
  Olympus: Li20B, VBA10, DL12, DB40
  Ricoh: DB40, DB43
  Samsung: 1037
  Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

Configuration système requise

- Navilock 61700 Maxi Charger

Contenu de l’emballage

© 2024 by Navilock. Tous les noms et images mentionnés ici sont la propriété de leur fabricant respectif. Sous réserve d’erreurs et de modifications.

- Charging plate

Image



© 2024 by Navilock. Tous les noms et images mentionnés ici sont la propriété de leur fabricant respectif. Sous réserve d'erreurs et de modifications.