

Navilock Charger Plate for MAXI Charger C1037

Popis

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



Číslo produktu 65722

EAN: 4043619657223

Země původu: China

Balení: Baleno v blistru

Specifikace

- Suitable for
 - Casio: NP30
 - FUJI: NP60, NP120, BT3, S301, 1037, 1137, DL-S5, DL-S6, DV-4, OD525
 - Kodak: K5000, K5001
 - Nikon: ENEL5, EL5
 - Olympus: Li20B, VBA10, DL12, DB40
 - Ricoh: DB40, DB43
 - Samsung: 1037
 - Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

Systémové požadavky

- Navilock 61700 Maxi Charger

Obsah balení

- Charging plate

Příslušenství

