

Navilock Charger Plate for MAXI Charger C1037

Description

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



Item no. 65722

EAN: 4043619657223

Country of origin: China

Package: Blister

Technical details

- Suitable for
 - Casio: NP30
 - FUJI: NP60, NP120, BT3, S301, 1037, 1137, DL-S5, DL-S6, DV-4, OD525
 - Kodak: K5000, K5001
 - Nikon: ENEL5, EL5
 - Olympus: Li20B, VBA10, DL12, DB40
 - Ricoh: DB40, DB43
 - Samsung: 1037
 - Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

System requirements

- Navilock 61700 Maxi Charger

Package content

- Charging plate

Images

