

Navilock Charger Plate for MAXI Charger C1037

Descripción

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



Número de elemento 65722

EAN: 4043619657223

Pais de origen: China

Paquete: Blister

Especificación técnica

- Suitable for
 - Casio: NP30
 - FUJI: NP60, NP120, BT3, S301, 1037, 1137, DL-S5, DL-S6, DV-4, OD525
 - Kodak: K5000, K5001
 - Nikon: ENEL5, EL5
 - Olympus: Li20B, VBA10, DL12, DB40
 - Ricoh: DB40, DB43
 - Samsung: 1037
 - Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

Requisitos del sistema

- Navilock 61700 Maxi Charger

Contenido del paquete



- Charging plate

Image

