

Navilock Charger Plate for MAXI Charger C1037

Description

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



N° produit 65722

EAN: 4043619657223

Pays d'origine: China

Emballage: Blister

Spécifications techniques

- Suitable for
 - Casio: NP30
 - FUJI: NP60, NP120, BT3, S301, 1037, 1137, DL-S5, DL-S6, DV-4, OD525
 - Kodak: K5000, K5001
 - Nikon: ENEL5, EL5
 - Olympus: Li20B, VBA10, DL12, DB40
 - Ricoh: DB40, DB43
 - Samsung: 1037
 - Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

Configuration système requise

- Navilock 61700 Maxi Charger

Contenu de l'emballage

- Charging plate

Image

