

Navilock Charger Plate for MAXI Charger C1037

Opis

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



Numer artykułu 65722

EAN: 4043619657223

Kraj pochodzenia: China

Opakowanie: Blister

Specyfikacja

- Suitable for
Casio: NP30
FUJI: NP60, NP120, BT3, S301, 1037, 1137,
DL-S5, DL-S6, DV-4, OD525
Kodak: K5000, K5001
Nikon: ENEL5, EL5
Olympus: Li20B, VBA10, DL12, DB40
Ricoh: DB40, DB43
Samsung: 1037
Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

Wymagania systemowe

- Navilock 61700 Maxi Charger

Zawartość opakowania

- Charging plate

Zdjęcia

